

# Light Object DSP Controller Setup Guide

By Tim Wehr

Last Updated 6/21/2010

## Background

I have been struggling with my Moshi-based laser for nearly a year. That software's capabilities are very limited and the whole system is extremely buggy and unreliable. (Your opinion may differ; mine is based on 35 years of software/hardware development.) I won't give details here, as I want to focus on a solution. But, given that you are reading this document, it is likely that you are realizing that there must be something better out there.

For anyone using Moshi-based software and controllers for your CO2 laser, the DSP Controller (from LightObject.com) is, quite simply, the best investment you can possibly make.

Before I go on, I want to make a couple of things very clear:

1. I purchased my Moshi-based laser from All Image Printing via eBay. For the original price, I was happy – just not satisfied with the capabilities of the software and controller. However, I would still happily do business with All Image Printing! My contact there, Benjamin, has been great – very helpful and generous with his time, effort, and assistance.
2. I have no personal connection with Light Object, other than being a customer. Over the past year I have purchased a number of items from them and always get good value. My contact there, Marco, is fantastic to work with. He openly admits that his “real-world” experience with lasers is a little limited, but his technical knowledge and customer-first attitude are great. He always impresses me with the way he conducts business.

My purpose for taking the time to write this Setup Guide is simple:

**I want to help you get your Light Object DSP Controller up and running quickly and easily.**

The forum at the Light Object web site has quite a bit of valuable information about the DSP Controller. Unfortunately, it is not well organized, making it difficult to find exactly what you need at any given moment. It is also missing one important item – a Setup Guide. There are several documents that adequately describe the characteristics of the controller, as well as operating instructions for the software. But they are basically “User” manuals and not “Setup” guides/manuals. The difference is this: A user manual is arranged to easily find the information you need when you know what you are looking for.

A setup guide is arranged to tell you what to do, in a step-by-step manner, to get started.

This document focuses on the latter – the step-by-step process of getting your Light Object DSP Controller up and running quickly, easily, and with the least-possible amount of frustration.

To that end, let's get started.

**DISCLAIMER (because I must) – The author explicitly disavows any responsibility for loss, damage, or injury as a result of your reading and interpretation of this guide. You assume full responsibility for verifying that the material here presented are appropriate for your situation and that you are capable of applying the ideas correctly and safely.**

**Note:** This is being written after the fact. In other words, I did not follow these steps, in the order presented, but I wish I had. It would have saved me at least 2-3 hours.

### **Assumptions**

It is impossible to know what someone else does or does not know. I will try to make as few assumptions about your knowledge/capabilities as possible. At the same time, we need to work from some common base. Here is what I suggest:

You should:

1. Have some knowledge of how to connect wires (via soldering or other secure means).
2. Have (and know the basic use of) a VOM [volt-ohm meter]. You may not need it, but if you do, it will save you time and frustration.
3. Have Corel Draw installed and working on your host computer. (I used ver. X4.)
4. **Have your OLD controller disconnected**, both externally (from the computer) and internally (from the power supply, the stepper motors, and from the laser power supply).

**Note - It is NOT necessary to remove the old electronics from your laser box, yet.** I did not. I wired everything up outside the box to ensure that I got it working satisfactorily. I wanted the option of easily returning to the original setup, if need be. Once everything was “proven” to work and I had a solid understanding of the new wiring, I removed the old guts, and laid out and installed the new board, drivers, and wiring.

### **Install & Setup Instructions**

As a broad overview, here are the major steps we will be taking (details to follow shortly):

- A. **Wire up** and **test** the **24V** dc power to the **Controller board**.
- B. **Install software** and **connect USB** from computer to controller.
- C. **Connect** remaining hardware and **set** laser and machine **parameters**.
- D. **Enjoy!**

Ok! There may be a few steps in between, but we will break them down as we go.


**Note:** You will likely be using the Light Object DSP Controller User's Manual, Specifications Manual, and Typical Minimum Setup documents, along side this document. That is fine; even recommended at time. Be aware, however, that the current document (as of 6/15/2010) is NOT for the current version of controller board, nor anything newer than Corel Draw v12. I will do the best I can to point out the differences as we go.

### Step A - Wiring Up the Power to the Controller Board

This is the first difference you will notice between the provided documentation and the actual controller.

**The current (6/15/2010) controller only requires +24Vdc power.**

The documentation calls for an additional +5V dc. This is no longer needed. All power is converted directly on board.



The location of the +24V dc power connection to the board is the same general location as it shows in the documentation, but has only a 2-wire connector instead of a 4-wire.

Also note that the diagram calls for only 1 amp. That is adequate for the controller board and display panel. If you are using the same power supply for the stepper drivers and the stepper motors, you will need more!


Testing the +24V dc Power Connection to the Controller.

We want to quickly verify that the controller is happy with the power connection we just made.

1. **UNPLUG** the power input connector from the Controller.
2. **Turn ON** the power supply.
3. Using your VOM [volt-ohm meter] **verify** that the **output** from the PS is +24V +/- 0.1 V dc, and that the wires are going to the correct posts on the connector.

(24+ will be next to the outside of the board, and 24 gnd will be towards the center of the board.)

4. **Turn OFF** the power supply.
5. **Connect** the power connector to the Controller Board.
6. **Turn ON** power supply.
7. After a few seconds, the Controller Board's **main LED indicator lamp** should be **flashing red**.



8. **Turn OFF** the power supply.

At this point we want to connect and verify that the Controller Panel (user controls) is working also getting powered up correctly.

9. Make sure the dc **power** supply is **OFF**.
10. **Plug** the **Control Panel Cable** into the **Controller Board**.
11. **Plug** the **Control Panel Cable** into the **Controller Panel**.
12. **Turn ON** power to the power supply.
13. **Verify** that **the Controller Panel display** shows the **Reset** and then the **general display** of (your values may be different):
  - File:** 000
  - Power:** 80%
  - Speed:** 400 mm/s
  - System Idle**
14. **Turn OFF** power to the power supply.

**Note:** The initial display will likely be in **Chinese**. To change to **English**:

- A. **Push** the **Language** key on the Controller Panel.
- B. **Push** the **Down Arrow** key on the Controller Panel until you get to **English**.
- C. Then **push** the **Enter** key on the Controller Panel.

**Note:** Yes, it all makes a terribly annoying sound when the system resets or a button is pushed. Haven't found a way around that, yet!

This concludes the first major step to getting your new controller installed and running.

### **Troubleshooting**

There is little that can have gone wrong up to this point. If you are not getting the results described, chances are you have the wrong voltage or you have the +24V and the 24V

gnd reversed. Either of these mean you skipped step 3 – verifying that it is right. (Thought you would not get caught, didn't you!)

If you did everything right, then it should be working. I believe Marco has said that they QA every board before it goes out. If still having issues, please contact Light Object.

### **Step B - Installing the Software and Connecting the Computer to the Controller**

It may seem a bit odd that we are putting both the software and a physical connection in to the same major step discussion. As it turns out, the act of plugging in the USB cable between the computer and the controller is what actually causes the computer to attempt to install a portion of the necessary software.


Remember our assumption that you had Corel Draw already installed and operational? All meaningful communications with the Controller Board are done from within Corel Draw. So, if you skipped over that, it is time to go back and do it. (I'll wait here!)

OK. Let's move on. As I just said, everything we need to do to get the controller configured for our laser is communicated via Corel Draw. Corel Draw will actually be talking to the controller via a special plug-in module. And for Corel Draw to even recognize the plug-in module, it needs to have that feature turned on.

I am going to outline the steps for getting the feature activated and the plug-in module installed in version X4 of Corel Draw. I believe this will work equally well for version X3. If you are using version 11 or 12, you can simply follow the directions provided by Light Object, starting at section 1.3, steps 1 and 2 (page 1 and 2) of the User's Manual. Stop immediately after step 2 (2.3 – closing Corel Draw) and come back. Meanwhile, we are going to go ahead with our X3/4 instructions for doing the same thing.

#### **IF you are using Corel Draw Version X3 or X4**

1. **Launch Corel Draw**
2. **Create a new (blank) document** (can't get at necessary options without an open document).
3. **Select Customization...** from the **Tools** menu.
4. In the dialog window that opens, **click** on **Command Bars**
5. **Click** on **Macros** (to add a checkmark, if already checked, leave it alone)
6. **Click** the **OK** button.



Somewhere in the Corel Draw workspace, you will see a new small toolbar that looks like this.




7. **Click** (in the title area of this toolbar) and **drag** it to any empty place in any of the other toolbars at the top of your window. (We won't actually be using it, but it needs to be "open" to get the rest of our software to work.)
8. **Close Corel Draw**. (The macro toolbar will automatically return each time we launch Corel Draw from now on.)

Now it is time to actually install the plug in mentioned earlier.


9. In the software package from Light Object, there is an application named **TZSetup**. (The older documentation refers to this as Rd\_Setup. It has been renamed.) Double-click this application to launch the installer.  
NOTE – If you get a security warning, it is OK and you should click Run.

The install dialog will come up in Chinese and look like this




10. **Select English** from the Dropdown menu.

11. **Click Install**



12. In the results dialog, **click OK.**



Both dialog boxes will now close.

13. **Connect** the **USB** cable into the Controller Board.
14. **Turn power ON** to the **24V dc power supply** (so the controller will be powered for the next steps).
15. **Connect the USB** cable into the **Computer**.

At this point, you may hear an audible tone from the computer and you may see a notification in the tool tray at the bottom right corner of your screen, indicating that new hardware has been found.

(**NOTE** – I do not have visuals available for this right now. Will try to get and install here later.)


Within a few seconds, you should get a dialog box open that talks about installing the drivers for this device. It will be asking whether you have a CD with the software. You want to set the dialog to include a custom location to search for the software. That custom location should be the folder (from Light Object) that contains the DSP drivers, depending on your operating system. It will be named **USB\_Driver-WinXP2K** for Windows 2000 or XP or **USBDRVE-Vista** for Vista (and possibly Windows 7?).

16. Once you have the custom location set, let the dialog continue on to do the install for you.
17. **Close** the driver installation **dialog**.

If these system did not ask to install the software (or did not recognize that you had attached a new device), it is likely that you do not have the controller board powered on and the computer does not know it exists.

18. **Launch Corel Draw** again.

19. From the **Tools Menu**, select **Customization...**



20. **Click** on **Commands** (NOT the Command Bars like before).

21. From the **popup list** (at top) select **Macros**

22. **Click** and **drag** the **Laser.UserInit** item outside of the dialog window into any part of the Corel Draw work area.

23. Then **click** **OK** to close the dialog window.

24. In the small toolbar window that opens, **double-click** the one and only tool that appears.



25. There will be another command bar open. **Click** and **drag** its title area to move it to any open space in the command bar area at the top of the Corel Draw window (just like we did earlier with the Macro command bar).



26. **Close** the remaining command tool bar window (with the single tool in it) by clicking the X in the upper right corner.

We're almost done with the software install. So hang in there.

27. **Click** the **Settings tool** in the Laser command bar we just installed.




**Note:** IF you get an error message saying Machine Connect, it means your USB is not connected to the Controller Board OR your power is off to the Controller Board. Make sure it is power ON and connected to your computer.

28. In the dialog window that opens, **verify** that “**AI – Adobe Illustrator**” is selected.

29. **Verify** (change if necessary) that the **language** is set to **English**.

30. Then **click OK** to close the dialog.



That's it for the software install. Next we will learn the correct order to make and configure the remaining hardware and software settings.

### **Step C - Connect Remaining Hardware and Set Laser and Machine Parameters**

This is surely going to be the most tedious and time-consuming part. It is also the part that allows me the least amount of specificity. Your laser may be entirely different than

mine. It may also be virtually identical, regardless of where you bought it. As I mentioned earlier, I purchased mine from the very good folks at All Image Printing. They, however, did not manufacture it. It was actually manufactured by YingHe company in China. They manufacture for a number of distributors, with only minor differences from one distributor to another. They all look pretty much alike. Here is a promo photo from AIP of mine.



Look especially at the button panel configuration. If yours is the same, chances are we have the same basic machine.

Regardless of whether our lasers are the same or not, much of what you need to do now requires eyes-on to get the job done. That doesn't mean this guide is not going to be useful. After stumbling for several hours myself, I believe I can now give you some critically important help; specifically, I can (and will) give you the necessary order of operations to ensure that you get everything set up quickly, and SAFELY. You don't want to destroy your laser with run-away electronics.

Overall, we plan to do the following major steps.

1. Connect **the limit switches** and set their **polarity** for correct operation.
2. Connect the **drivers** and **drive motors** and set their **Direction Polarity**.
3. Set the **Keying Direction**.
4. Set the **Length** (adjust step distance to ensure that the output is same size as input).
5. Set the **maximum size of your work area**.

Along the way, we will also discuss the concepts of **max speed** and **acceleration**.


You MAY want to refer to the User's Manual as we work through these items. That is fine to do. Just be sure to use this document for the order of operations.

### **Limit Switches**

Most computer driven machines have limit switches – some means of detecting when a moving part (in this case, the laser head) reaches some physical limit. At the very least, most lasers have one set of limit switches located at the 0,0 (0 mm in the X direction, and 0 mm in the Y direction). When these limit switches are engaged by the moving laser

head, a signal is sent to the Controller Board that lets it know that the head is now in the “home” or “machine origin” position. When the Controller Board receives that signal, it knows it is time to cease sending movement signals to the motor drivers. This prevents the head from crashing into the sides of the machine work area. So, it is good and wise that we set them up first.

All limit switch connections to the Controller Board are made in on one connector plug.



There are many different types of limit switches, all working somewhat differently. They may be mechanical (physical contact required to engage), or they may be optical, requiring only an interruption of an internally-generated light source, usually by a thin metal “blade” that passes through the beam of light it is internally generating and reading. Either way, it is likely you are going to need some power passing through this switch to be either sent or stopped when the switch is engaged.

**The Controller Board provides both +5V dc and Ground connections for your use.**

These are available on pins 6 and 1 respectively, of the same connector. In other words, if your switches needs power, get the **+5V from pin 6** and the **Ground from pin 1**.

The return signal from your switches will be tied to pins 4 (X) and 2 (Y).

- a. At this point, you need to connect **your home limit switches** to the appropriate pins of the connector.


The graphic above shows that a “**Signal LOW (gnd)**” is expected whenever a home limit switch is engaged. There is a very real possibility that your limit switches actually do the opposite. In other words, they are already at ground, but go high (between 2.4 and 5 volts) when engaged. This is not a problem, as the **Controller Board** can be taught to **adapt its behavior accordingly**.

But how do you know whether you need to tell it to adapt or not? It is really quite easy.


Each of the limit signal connectors (pins) has an indicator LED that lights up (Red) whenever it is receiving a Signal LOW (gnd) signal. Conversely, when receiving a Signal HI (between 2.4 and 5 volts), the LED is no longer lit. So, all we have to do is power up, move the laser head (by hand), and observe the indicator LEDs. Let’s do that now.

- b. **Turn the power on** to the Controller Board. If you used power from the limits connector pins 1 and 6 to power the limit switches, they should also be power up.
- c. **Move the laser head** (by hand) to someplace near the middle of the work area. (We can do this manually, because the drive motors and drivers are not yet connected.)
- d. **Observe** the row of indicator **LEDs** just above the connector.

IF none of the LEDs are lit, then your switches will likely send the desired Signal LOW (gnd) signal when the switch is engaged. (We'll verify this in a moment.)



IF the LEDs for pins 2 and 4 are lit (Red), then your switches are likely sending the Signal LOW (gnd) signal when NOT engaged. (We'll verify this in a next.)



- e. **Verify** our preliminary findings.
  - 1) **Move the laser head** (by hand) to engage **ONE** (x or y, doesn't matter) of the home limit switches.
  - 2) **Observe** the **LED** associated with that limit switch. It should change state. If it was previously unlit, it should now be lit. If it was previously lit, the light should have now gone out. **IF the LED did NOT CHANGE STATE**, then you have a wiring issue; go back and correct it before moving on.
  - 3) **Move the laser head** (by hand) to engage the **OTHER** limit switch.
  - 4) **Observe** the **LED** associate with that limit switch and see that is behaves like the first one.

**NOTE:** Regardless of which way your limit switches are working, they should change state as you engage the switch and flip back again when you disengage the switch (move away from it). If they are NO changing state, fix any wiring issues. **We can't wire up the drive motors until it is safe to do so, and it is not safe until the limit switches function correctly.**

- 5) **Make a note** of which way your limit switches work.  
**IF engaging switch turn LED ON** – then your limit switch polarity is **NEGATIVE**.  
**IF engaging the switch turns LED OFF** – then your limit switch polarity is **POSITIVE**.
- f. **If** your polarity is **Negative**, you are finished with the limit switch setup.  
**If** your polarity is **Positive**, you need to tell the Controller Board to adapt its behavior accordingly. We'll do that now.

In order to make ANY changes to the Controller Board, we need to revisit Corel Draw. Remember that I said that all communication with the Controller Board is done via the plug-in module we previously installed in Corel Draw? It is time to learn how that works.

- 1) **Launch** Corel Draw (if not already running).
- 2) **Verify** that the **Controller Board** is also **powered on** and **connected**.
- 3) In the laser command bar, click the **Laser Running** tool.



- 4) In the dialog window that opens, **click** the **Machine Para.** tab.
- 5) **Click** the **Read** button at the bottom of the dialog window. This will bring in the current board setting. You should get a little message box telling you that it read successfully. Just dismiss this message box.

**Important** – until you have done so, the **Write** button will not be available to you, so you won't be about the send your changes to the board.

- 6) We want to change the Limit Polarity (because we found that ours is Positive and the default is set for Negative). Above the read/write buttons is a list of parameters that can be set for any axis. The currently selected axis is near the top (probably set to X). **Find the Limit Polarity** entry and **change** it to **Positive**.
- 7) **Change** the **Axis** we are working with (to Y).
- 8) **Change** its **Limit Polarity** to **Positive**, as well.
- 9) **Click** the **Write** button. (If it is grayed out and disabled, you forgot to Read in the current settings – step 5 above.)
- 10) You will be asked for a password to authorize the changes

The password is **gxfc88**

It is case sensitive **enter password** exactly as you see here.

11) You should get a message box indicating success. **Dismiss the message box.**

That's it for wiring and setting the limit switches. If you have additional limit switches (for Max X and Max Y), you can wire them up similarly using pins 3 and 5 of the limits connector.

### Connecting the drivers and drive motors and setting their Direction Polarity

This is likely to be the most time-consuming part of the whole process. Not because it is so hard, but because there are lots of wires to connect.

I can't begin to tell you how to wire up every different kind of motor driver and drive motor. There are too many possibilities. So I am going to discuss the wiring using the motor driver I used, the PSD5042-2P, which is also from Light Object.



To wire up this motor driver, you need to make the following connections.

**Make sure the controller and power supply are OFF before making any connections.**

*Connections to DSP Controller Board (using upper connection block in picture).*

Motor Driver

**PUL+**  
**PUL-**  
**DIR-**  
**DIR+**

DSP Controller

**Pin 4 PWM-** (other drivers may call this "Step-")  
**Pin 5 PWM+** (other drivers may call this "Step+")  
**Pin 3 DIR-**  
**Pin 2 DIR+**

I know – the +/- are counter intuitive, but the above IS CORRECT, for this driver at least.

*Connections to Drive Motors (using lower connection block in picture).*

Motors likely have two pair of wires (total 4 wires). If you are not sure which two are paired, don't worry too much about it. If mismatched, they simply won't work. If matched, all will work well.

**Connect one pair to the A +/- combination.**

**Connect the other pair to the B +/- combination.**

When we test, (soon), if we find that nothing works, we simply swap any two wires. If we find it is working, but moving the wrong direction, we will change the Direction Polarity in the software.

*Connections to power (using the lower connection block in picture).*

**Connect the +V to +24V (24 to 50) from power supply.**

**Connect the Gnd to ground from power supply.**

That's it for the physical connections. Now we want to test and set the Direction Polarity, is necessary, so everything is moving the right way.

**STOP.** Before you move on, pull the lower (in picture) wiring connector on the Y motor driver. This will disconnect the power wiring between the driver and the motor. That means, when we apply power we can focus exclusively on only one axis (X).

**Here is our first test of the motor drivers and their wiring.**

- a. **Ensure** the **Y axis** is **disconnected** at the motor driver (removing power lines as well as the motor wirings).
- b. **Move** (by hand) **the laser head** to the middle part of the laser work area. (The head should start moving as soon as we apply power to the Controller Board and the motor drivers; we need to have room for it move without crashing into anything.)
- c. If power supply for motors is different from power supply for controllers, turn motors power supply on.
- d. **Turn on power to Controller Board.**
- e. **Observe** which **direction** the head is moving. (Should be only the X axis moving.)

Is it moving **TOWARD** the **Home Limit position**,  
or is it moving **AWAY** from the **Home Limit position**.

**IF moving AWAY – Kill the power immediately**, as it is moving the wrong direction. We will fix this in the next step.

**IF moving TOWARD – let it continue** on to the X home position. **When it gets there**, it **SHOULD stop** after sending the limit switch signal to the Controller Board. **BUT, be prepared to kill the power if it gets there**

**and does not stop – starts banging into the side.**


Obviously, **if the X axis does NOT move at all, BUT the Y DOES**, you have the **X and Y reversed**. Kill the power, **swap the X and Y connectors** on the Controller Board, and start the testing again.

f. **Change the Direction Polarity** (if necessary) in the software from within Corel Draw.

- 1) **Disconnect the X axis** (the Y axis should have already been disconnected) from the Controller Board. Remember, every time we power up or reset the controller, the controller will attempt to “home” any connected motors and we already know it is running backwards. **AFTER** we adjust the Direction Polarity, we can plug it back in and test.
- 2) **Launch** Corel Draw (if not already running).
- 3) **Verify** that the **Controller Board** is also **powered on** and **connected**.
- 4) In the laser command bar, click the **Laser Running** tool.



5) In the dialog window that opens, **click the Machine Para. tab**.



(**Note** – this image is from the Light Object documentation and is slightly different from the current version, but for purposes of its setup guide, it is adequate for you to be able to locate the various parameters being discussed.)

- 6) **Click the Read button** at the bottom of the dialog window. This will bring in the current board setting. You should get a little message box telling you that it read successfully. Just dismiss this message box.

**Important – until you have done so, the Write button will not be available to you, so you won't be about the send your changes to the board.**

- 7) We want to change the **Direction Polarity** (because the head is moving the wrong way). Above the read/write buttons is a list of parameters that can be set for any axis. The currently selected axis is near the top (probably set to X). **Find the Direction Polarity entry and change it to Positive.**

**(NOTE – We will not automatically change the Y axis as we have not tested it yet. Unlike the Limit Polarity, where both will be likely to be the same, the Direction Polarity depends on how you wired it up. If you were consistent in your wire color ordering, X and Y could be the same, but best to test after we finish with the X.)**

- 8) **Click the Write button.** (If it is grayed out and disabled, you forgot to Read in the current settings – step 6 above.)
- 9) You will be asked for a password to authorize the changes

The password is **gxfc88**

It is case sensitive **enter password** exactly as you see here.

- 10) You should get a message box indicating success. **Dismiss the message box.**

Now you can power down the Controller Board, reconnect the X axis (only) and power up again. This time, the X axis SHOULD be moving the correct direction, towards your X home limit switch. In fact, since we already set the limit switches, the head should move until the limit switch is engaged, and then stop nicely.

The next thing to set up is the Keypad direction polarity for the X axis. This is going to be very similar to the Limit Polarity and the Direction Polarity we already tested and fixed, if necessary.

To test the Keypad direction:

- 1) Make sure you have the **X axis (only) connected.**
- 2) **Power on the Controller board** (or press the Reset button on the controller, if it is already powered up).
- 3) **Press one of the horizontal (left or right) keys** on the Control Display board. If your "Home" limit for X is at the Left, then press the Right Arrow.

- 4) **Observe** if the laser head moves **AWAY** from the **home limit**.

**If limit at left and you press right key and head moves right, you are done.**

**If head does not move, try pressing the other direction.**

**If head does not move, regardless of the direction you push, you probably did not get X axis reconnected, or the Controller Board power is not on.**

- 5) **IF head moves opposite of the direction you are pushing**, you need to change the Keypad Polarity. This is done in the same manner as we changed the Limit Polarity and the Direction Polarity.

**From this point on, I will NOT be repeating the directions for making changes. Simply refer to the previous changes. You should have the hang of it now.**


OK. There are still a couple of configuration items to verify, but first, **go through all the above steps with the Y axis**, so that we are confident that for **BOTH X and Y axes**, the **limit switches work correctly, the head moves the correct direction on power on/reset**, and the **head moves correctly when we press any of the keypad direction keys**.

**Note:** At this point (or possibly even earlier), it is possible that the **head is moving erratically**, either at power on/reset or when pressing the direction keys. There are two primary causes of this. **1)** The max and/or acceleration rates are too high, or **2)** the step size is too small (meaning it thinks it is only trying to move a very small distance, but the actual distance the head is trying to move is very large).

The first possible cause is easy to fix. Just use our usual parameter changing technique and reduce the max speed (down to about 50 mm/s for now), and the acceleration (down to about 1000 mm/s/s for now). After everything else is done, you can go back and fine tune the max speed and the acceleration speed.

The second issue is a little trickier, but it is time to be working calibrating our step distance anyway.

**Before you can calibrate the step distance**, you must have the laser power supply connected to the controller board. The way you connect the laser power supply to the controller board depends on the type of laser power supply you have. The Basic Minimum Wiring diagram from Light Object is **ALMOST** correct for wiring up their laser power supply when configured for WPM (preferred method). Unfortunately, the controller board has changed since that documentation was produced, so it has a mistake in it.



**The TL terminal on the power supply is NOT connected to pin 2 of the Controller Board laser terminal. Rather, it now needs to be connected to pin 3.**

If you have a different power supply, you are welcome to contact me and I will try to help you out (no promises about if I will be able to do so).

Hopefully, you have the laser connected and working. If you have it connected but not tested yet, just power everything up and press the Laser button on the Control Display panel. That should fire the laser.

Now we can actually **test to see if the head is moving the correct distance** or not.

The documentation from Light Object actually does a pretty good job of telling you how to test and adjust the step size, so I am not going to repeat it all here. **The is one exception**, though. It suggests that you use a large test rectangle. Don't do that yet! **Start with a small one, instead.** If your test rectangle is too large, and your step size is too small, you will send your laser head crashing into the X or Y maximum walls. Start with a 20mm x 20mm square for the first test. Then, **AFTER** you have the step size set close to correct, you can retest with something larger (250,250).

Now you have the step size correct. There is really only one additional item to get right as soon as possible, the maximum travel in both the X and Y directions. Just like the limit switches that stop the head movement at the Home position (0,0), setting the maximum distance the head can travel will prevent you from crashing when you inadvertently tell it move beyond the limits of your workspace.

I simply measured (manually) the maximum travel in each direction, and set the values accordingly. Then tested to see what would happen if I tried to move it “too” far. Works great.

### **Where to Go from Here!**

If you successfully followed everything, you should now have your laser converted to use the DSP Controller Board from Light Object. Specifically, you should:

- Have the **limit switches wired and configured and working properly.**
- Have the **X and Y drivers connected** to the Controller Board.
- Have the **X and Y motors connected** to the X and Y drivers and **working correctly.**
- Have the **X and Y step distances calibrated.**
- Have the **Laser power supply connected and working properly.**

Obviously, there has been lots of room for mismatching between my experiences and equipment and your experiences and equipment. This was not intended to be the perfect solution for all situations, but only a helpful guide to your thinking and general process that will prevent you from too many crashes.

If you find something specifically wrong (meaning untrue, not just incorrect for YOUR situation), please let me know. If you wish to extend this document and add specific information that matches different equipment or situations, by all means let me know.

Most important, realize that the DSP Controller from Light Object is, dollar-for-dollar, probably the best value you will find. It definitely brings you out of the hobby environment and into the commercial world. I truly hope you enjoy it as much as I am.